

HLF 5700



TRANSPORT WARNINGS

During the transport of the HLF 5700 coffee maker it is important to <u>avoid</u> the following operations:

- → Turning the box upside down or lay it down on its side
- → Dropping the box
- → Exposing it to rain, excessive cold/heat or damp places



NOTE

Before opening the box of the HLF 5700 coffee maker, check out the packaging to be sure there is no damage. If damage is noticed, place a claim with the freight forwarder immediately.

Check for:

- → Dents or damage of the box
- → Wet areas
- → Signs of tampering

INSTRUCTION MANUAL

Scan the below QR Code or click on the following link to access the instruction manual of the machine:



https://kutt.it/IM-5700-Eng

The instruction manual can also be consulted directly from the machine setting menu.

In order to preserve the integrity and functionality of the machine, we recommend to:

- → Read carefully the installation procedure (see Ch. 3 – Instruction Manual)
- → Keep the machine clean in all its parts (see Ch.4 - Instruction Manual)
- → Use only authorized products as listed in the Instruction Manual (e.g. detergents)





HLF S.r.l.
Via Postioma, 34
31050 Vascon di Carbonera | Treviso | Italy
T +39 0422 969 205 | F +39 0422 963 933
www.hlf.it | info@hlf.it